


Playback

Click  button to playback

No. 1 player mode:



The choice of date: Representatives of red fonts are video



Screenshots



Open since definition video



Photo Show



Second playback mode switch



1 Scr



4 Scr



9 Scr



16 Scr



Screen



Fast



Play



Suspended



Stop



Slow



Begin




Before the second




After the second




End



The minutes of the time that



The hours of the time that




The channel of choice

The first player mode players Process:

Selection Date →→ Selection of channel →→ Choose small hours of video →→ Select minutes of video →→ Players

This can be broadcast simultaneously over the same time video.

The second mode of play:



The choice of date: Representatives of red fonts are video



Screenshots



Open since definition video




Photo Show



Second playback mode switch



The channel of choice



All current video channel



Good choice for the video player



Screenshots



Open since definition video



Open voice regulation



1 Scr



4 Scr



9 Scr



16 Scr



Screen



Player



Suspended



Video stop current window



All video stop



Begin



Before the second



After the second



Fast



Slow



End



Close

The second player mode players Process:

Selection Date →→ Selection of channel →→ The list of choices in the video broadcast
needs time (A good choice in the list of players automatically adds video) →→ Player

If you want to delete the list of players in a video, It can be that you want to delete the video on the line.